



## pvc ceilings

### Prior to installation

- Ensure that PVC Ceilings are not exposed to direct sunlight. There are no UV stabilizers in the product and exposure to direct sunlight will alter the colour over time
- Check the batch numbers and ensure that one batch number is used in one area
- The colour/shade of the product is not guaranteed across batches
- The product needs to be checked prior to installing for colour variation and any indentations or visual defects
- No claims will be entertained after installation

### Installation instructions

- Brandering spacing needs to be a maximum of 500mm apart.
- Ensure that brandering is lined up perfectly and is level / horizontal.
- PVC Ceiling panels can be fitted onto Steel Brandering or Wooden Battens 38mm X 38mm using a Drywall Screw (Timber – course thread / Steel – fine thread).
- Screw your PVC Ceiling panel onto the brandering.
- The screw must not break through the PVC panel.
- The panels must lay in the same direction as the main trusses.
- Make sure the screw head fastens properly and is flush with the groove of ceiling panel.
- Clip the second panel with the tongue onto the groove of first panel.
- Knock panel gently on the side to secure close fitment. (Use your hand palm)
- Do not carry on until the panel is fitted correctly.
- In order to fit the last panel, cut the panel lengthways with a carpet knife.
- Close the corners with cornice.
- Dust ceiling with a cloth after fitment is done

